

# Maintenance

## Periodic maintenance chart

Frequency of maintenance operations may be adjusted according to the operating conditions, but the following table gives general guidelines.

●: Indicates the checkups which you may do yourself.

■: Indicates work to be done by a Yamaha Boat Dealer.

Maintenance Interval		Initial			Thereafter Every		Page
		10 hours	50 hours	100 hours	100 hours	200 hours	
			6 months	12 months	12 months	24 months	
Spark plugs	Check/Clean/Adjust	■	■	■	■		—
Grease points	Lubricate			●	●		122
Bearing housings	Lubricate	■		●	●		123
Fuel system	Check			■	■		127
Fuel filter	Check/Replace			■	■		—
Fuel pump screen	Clean			■	■		—
Air filters	Check/Replace				●		128
Engine oil	Replace	■		■	■		129
Engine oil filters	Replace				■		129
Valve clearance	Check/Adjust					■	—
Cooling water passages	Clean/Flush	● (After every use)					117
Bilge strainer	Clean		■	■	■		—
Impellers	Check		■	■	■		—
Steering cables	Check					●	130
Remote control levers	Check/Adjust			■	■		130
Shift gate mechanisms	Check			●	●		131
Sacrificial anodes	Check/Replace as needed	● (After every use)					132
Drain plugs	Check/Replace					●	97
Battery	Check	●					132
Rubber couplings	Check					■	—
Bolts and nuts	Retighten	■		■	■		—